

Can-Am Defender Front Bumper Installation



- 1) Remove Battle Armor Front Bumper and hardware from box. Hardware supplied is shown below.

Contains the following: (2)- 5/16" x 1" carriage bolts, (2) 5/16" flat washers, and (2) 5/16"-18 Nylon insert locknut.



- 2) Loosen the two torx head bolts located on front of Defender. Slide the open ended mounting bumper tabs over the torques head bolts and let bumper hang.



- 3) Using the supplied hardware bolt the lower bumper tabs to deflector plate. Tighten all hardware.



- 4) Note if installing light bar. Mount light bar to bumper before installing bumper.

